



Parts List Liste des pièces



Anti Tipping Kit
Anti Tipping Kit **x 1**



Wooden Knob
Bouton en bois **x 11**



40mm Bolt
Vis à bois **x 11**





WARNING

Injury may result from tipping furniture. This restraint is not a substitute for proper adult supervision. This restraint may provide protection against tipping furniture. Do not allow children to climb on furniture. Failure to detach this restraint before moving furniture may result in injury and damage.





AVERTISSEMENT

Incliner les meubles peut causer des blessures. Ce dispositif n'est pas un substitut à la surveillance des parents. Ce dispositif protège du basculement des meubles. Ne pas autoriser les enfants à grimper sur les meubles. Enlever ce dispositif avant de déplacer le meuble pour éviter tout risque de blessures et de dommages.



Wood or Metal Knob
Bouton de bois ou
Bouton de métal

Latch behind hinged bottom rail
L'attache derrière la rail du bas penturé



Secrets Tray
Cabaret "Secrets"